# Installation and Operation Manual

QTrack<sup>™</sup> Antenna System



Quasonix, Inc. 6025 Schumacher Park Dr. West Chester, OH 45069 17 October 2024

\*\*\* Revision 1.0.1 \*\*\*

Specifications subject to change without notice.

All Quasonix antenna products are under U.S. Department of Commerce jurisdiction categorized as 5A991; not covered by ITAR.

No part of the document may be circulated, quoted, or reproduced for distribution without prior written approval from Quasonix, Inc.

Copyright Quasonix, Inc., All Rights Reserved.

### **Table of Contents**

1 Introduction		. 1		
	1.1	Desc	ription	. 1
	1.2	Nom	enclature	.2
	1.2	1 O	otions and Accessories	.2
	1.2	2 St	andard Package Contents	.3
2	Spe	ecificatio	ins	.4
3	Inst	allation	Instructions	.5
	3.1	Mecl	nanical	.5
	3.1	1 Sy	vstem Configuration	.5
	3.1	2 2l	J Rack-Mount Controller	.5
	3.2	Envi	onmental	.7
	3.3	Elect	rical	.7
	3.3	1 21	J Controller Rear Panel Connections	.7
4	Ope	erating I	nstructions	.9
4	Оре 4.1	erating I Loca	nstructions I Antenna Control Unit (ACU) Operation	.9 .9
4	Ope 4.1 4.1	erating I Loca	nstructions I Antenna Control Unit (ACU) Operation emote ACU Operation	.9 .9 .9
4	Ope 4.1 4.1 4	Loca Loca 1 Ro .1.1.1	nstructions I Antenna Control Unit (ACU) Operation emote ACU Operation Remote Access Set Up, LAN	.9 .9 .9 .9
4	Ope 4.1 4.1 4.2	Loca Loca 1 Ro .1.1.1 ACU	nstructions I Antenna Control Unit (ACU) Operation emote ACU Operation Remote Access Set Up, LAN Main Operations Indicators and Manual Control	.9 .9 .9 .9
4	Ope 4.1 4.1 4.2 4.2	Loca Loca 1 Ro .1.1.1 ACU 1 A0	nstructions I Antenna Control Unit (ACU) Operation emote ACU Operation Remote Access Set Up, LAN Main Operations Indicators and Manual Control CU Menu Bar	.9 .9 .9 .9 10
4	Ope 4.1 4.1 4.2 4.2 4.2 4.2	Loca 1 Ro 1.1.1.1 ACU 1 AC .2.1.1	nstructions I Antenna Control Unit (ACU) Operation emote ACU Operation Remote Access Set Up, LAN Main Operations Indicators and Manual Control CU Menu Bar	.9 .9 .9 10 11
4	Ope 4.1 4.2 4.2 4.2 4.2 4.2	Erating I Loca 1 Ro .1.1.1 ACU 1 AC .2.1.1 .2.1.2	nstructions I Antenna Control Unit (ACU) Operation emote ACU Operation Remote Access Set Up, LAN Main Operations Indicators and Manual Control CU Menu Bar	.9 .9 .9 10 11 11
4	Ope 4.1 4.2 4.2 4.2 4.2 4.2 4.2 4.2 4.2 4.2 4.2	Erating I Loca 1 Ro .1.1.1 ACU 1 AO .2.1.1 .2.1.2 .2.1.3	nstructions I Antenna Control Unit (ACU) Operation emote ACU Operation Remote Access Set Up, LAN Main Operations Indicators and Manual Control CU Menu Bar	.9 .9 .9 .9 10 11 11 12 13
4	Opd 4.1 4.2 4.2 4.2 4.2 4.2 4.2 4.2 4.2 4.2 4.2	Loca 1 Ro 1.1.1.1 ACU 1 ACU 2.1.1 .2.1.2 .2.1.3 4.2.1	nstructions I Antenna Control Unit (ACU) Operation emote ACU Operation Remote Access Set Up, LAN Main Operations Indicators and Manual Control CU Menu Bar Logging Status Status	.9 .9 .9 10 11 11 12 13 14
4	Ope 4.1 4.2 4.2 4.2 4 4 4	Erating I Loca 1 Ro .1.1.1 ACU 1 ACU .2.1.1 .2.1.2 .2.1.3 4.2.1 4.2.1 4.2.1	nstructions I Antenna Control Unit (ACU) Operation	.9 .9 .9 10 11 11 12 13 14 14
4	Ope 4.1 4.2 4.2 4.2 4 4 4 4 4	Loca Loca 1 Ro .1.1.1 ACU 1 ACU 1 ACU .2.1.1 .2.1.2 .2.1.3 4.2.1 4.2.1 4.2.1 4.2.1	nstructions I Antenna Control Unit (ACU) Operation emote ACU Operation Remote Access Set Up, LAN Main Operations Indicators and Manual Control Main Operations Indicators and Manual Control CU Menu Bar Logging Status Settings 3.1 This Computer 3.2 ACU 3.3 Calibration Tools	.9 .9 .9 10 11 11 12 13 14 14 14
4	Ope 4.1 4.2 4.2 4.2 4 4 4 4 4 4 4 4 4 4 4	Erating I Loca 1 Ro .1.1.1 ACU 1 ACU 1 ACU .2.1.1 .2.1.2 .2.1.3 4.2.1 4.2.1 4.2.1 .2.1.4 .2.1.5	nstructions I Antenna Control Unit (ACU) Operation emote ACU Operation Remote Access Set Up, LAN Main Operations Indicators and Manual Control CU Menu Bar Logging Status Status Settings 3.1 This Computer 3.2 ACU 3.3 Calibration Tools Help	.9 .9 .9 10 11 11 12 13 14 14 14 14 14

# QTrack™ Antenna System

	4.2.3	Cam	mera Control	17
4	.3	System	m Tracking	18
	4.3.1	Basi	sic Tracking	18
	4.3.2	Targ	get Dynamics	18
	4.3.3	Mult	Itipath Clipping Angle (MPC)	19
	4.3.4	Acqu	quire	20
	4.3.5	Sea	arch	21
	4.3.6	Desi	signate Mode	21
	4.3	.6.1	Immediate Designate Mode	22
	4.3.	.6.2	Program Designate Mode	22
	4.3.7	True	e North Calibration	23
4	.4	Slaving	g and Burn File Operation	24
4	.5	Basic C	GUI Tool Set Functions	24
	4.5.1	Log	gging	25
	4.5.2	Han	nd Wheel Test (Optional)	26
	4.5.3	Joys	vstick Test (Optional)	27
5	Maint	enance	e Instructions	28
5	.1	Replac	ce the Battery	28
6	Produ	ict Warr	rranty	
7	Techr	nical Su	upport and RMA Requests	31
8	Apper	ndix A –	- Transmitter Control	
9	Appendix B – Acronym List			

# List of Figures

Figure 1: QTrack™ Antenna System Part Number Construction	. 2
Figure 2: Typical System Configuration, Local Operation	. 5
Figure 3: Mechanical Drawing – 2U Front View	.6

## QTrack™ Antenna System

Figure 4: Mechanical Drawing – 2U Back View	6
Figure 5: Mechanical Drawing – 2U Top View	6
Figure 6: 2U Front Panel	7
Figure 7: 2U Rear Panel	8
Figure 8: Typical System Configuration, Remote Operation—LAN Access	10
Figure 9: QTrack ACU Desktop Icon	11
Figure 10: QTrack ACU Graphical User Interface	11
Figure 11: Menu Bar, Logging Icon	12
Figure 12: Menu Bar, Logging Enabled	12
Figure 13: Menu Bar, Status Icon	12
Figure 14: Status Window	13
Figure 15: Menu Bar, Settings Icon	13
Figure 16: Settings Window	14
Figure 17: Menu Bar, Tools Icon	15
Figure 18: Tools Window	15
Figure 19: Menu Bar, Help Icon	15
Figure 20: Axis Control Window, Red Servo Button	16
Figure 21: Axis Control Window, Servo Button Changed to Green	16
Figure 22: Elevation, Tracking Error, Azimuth Windows	17
Figure 23: Axis Control Window, Manual Mode Buttons	17
Figure 24: Camera Control Window	18
Figure 25: Track Settings Window	19
Figure 26: AGC Window	20
Figure 27: Acquire Settings Window	20
Figure 28: Search Settings Window	21
Figure 29: Axis Control Window, Designate Button	22
Figure 30: Axis Control Window	22
Figure 31: Settings Window	23
Figure 32: True North Window	24
Figure 33: Tools Window	25
Figure 34: Logging Window	25
Figure 35: Elevation and Azimuth Input Control Windows	26
Figure 36: Hand Wheel Test Window	26
Figure 37: Joystick Test Window	27
Figure 38: Location of Battery on Motherboard of Older Units	28
Figure 39: Location of Battery on Newer Units	28
Figure 40: QTrack ACU Graphical User Interface	32

# QTrack™ Antenna System

Figure 41: Tx Control Window	32
Figure 42: Transmitter Window, Tx Settings Tab	33

### List of Tables

Table 1: Model Configuration Example	2
Table 2: 2U Rear Panel Connectors	8

### 1 Introduction

### 1.1 Description

This document describes the installation and operation of the Quasonix QTrack<sup>™</sup> Antenna System and is updated to match RDMS<sup>™</sup> System Version 19.3. The QTrack<sup>™</sup> antenna is enhanced by our industry-leading innovations, including our ultra-fast electronic scanning, enhanced system status graphics, and intuitive user interface. The standard QTrack Antenna System includes:

#### **Dual Axis Pedestal Assembly**

• Dual-axis positioner, slip ring, and two channel rotary joint assembly

#### SCM Antenna Assembly

• SCM antenna, with LHCP and RHCP outputs capable of operation at any or all of the following bands:

1435.5 MHz to 1534.5 MHz 1750.0 MHz to 1850.0 MHz 2200.5 MHz to 2394.5 MHz 4400.0 MHz to 5150.0 MHz (Extended operating frequencies available)

- A two-by-two antenna array providing dual axis tracking capability
- An RF assembly integrated behind the antenna array containing:
  - Tracking hybrid assemblies
  - Band pass filters for each polarization
  - Low noise RF preamplifiers for each polarization

#### **Rack Mounted 2U Control Unit**

- Ethernet control and status
- HDMI video port for interfacing to HDMI monitor (available accessory bundle)
- Front and rear panel USB ports for connecting keyboard and mouse (available accessory bundle)

#### System Cable Set (Length to be specified by Customer)

- Two LMR-400 RF cables
- One Control umbilical cable

The QTrack<sup>™</sup> Antenna System is manufactured by:

Quasonix, Inc. 6025 Schumacher Park Drive West Chester, OH 45069 CAGE code: 3CJA9

### 1.2 Nomenclature

The QTrack<sup>™</sup> Antenna System is available in a number of variations, depending on the options specified at the time of order. The features and modes installed in each unit are identified in the model number, as depicted in Figure 1.



Figure 1: QTrack<sup>™</sup> Antenna System Part Number Construction

For example, model number QSX-QTM-050-CA-TR defines a unit configured as shown in Table 1.

Identifiers	Description
QSX	Quasonix product
QT	QTrack Antenna System
М	L and S bands
050	Cable length for control umbilical and RF cables, in feet
СА	Camera option
TR	Tripod option

Table 1: Model	Configuration	Example
----------------	---------------	---------

Specifications are subject to change. Contact Quasonix for questions regarding your specific system.

#### 1.2.1 Options and Accessories

The available options and accessories include:

CA	Camera
TR	Tripod
TX05	5 Watt Integrated transmitter
TX10	10 Watt Integrated transmitter
QSX-AC-HWHEELS	Dual USB hand wheels

#### 1.2.2 Standard Package Contents

The contents of the shipment include the following:

- Round antenna
- Dual-Axis positioner
- 2U rack mount controller
- (2) 161005-xxx Coaxial cables
- QC-CBL005-XXX QTrack control umbilical cable

# 2 Specifications

Antenna Specifications		
Operating Frequency	1435.0 - 2500.0 MHz continuous	
	4400.0 - 5250.0 MHz continuous	
	Actual operating band based on selected filters	
Polarization	Receive: Simultaneous Right Hand and Left Hand Circular	
	Transmit (with TXnn options): Left Hand or Right Hand Circular	
Axial Ratio	2.0 dB maximum	
Antenna Type	Electronic Scanning	
Array Size (Diameter)	13.25 inches nominal	
Weight	Feed: 44 lbs Camera (optional): 6.5 lbs	
Antenna Gain (nominal	1435.0 MHz +7.0 dB	
linear polarized receive,	2400.0 MHz +10.0 dB	
RHCP and LHCP outputs	4400.0 MHz +9.0 dB	
combined)	5250.0 MHz +9.0 dB	
Antenna Beamwidth	40° (3 dB) (nominal)	
Sidelobes	10 dBp (nominal)	
Environmental		
Temperature	Operating -30°C to +55°C Storage -40°C to +71°C	
Relative Humidity	Up to 100%, including condensation (radome protected)	

### **Pedestal Specifications**

Туре	Elevation/Azimuth
Azimuth Travel	Continuous
Elevation Travel	-20° to +90°
RF Cabling Capability	Two RF channels supporting frequencies through C-band, VSWR 2.0:1 Maximum each RF channel
Weight	32.5 lbs nominal
Environmental	
Operating Temperature	-30°C to +55°C
Storage Temperature	-40°C to +71°C
Relative Humidity	Up to 100%, including condensation

### **3** Installation Instructions

### 3.1 Mechanical

#### 3.1.1 System Configuration



Figure 2: Typical System Configuration, Local Operation

#### 3.1.2 2U Rack-Mount Controller

The 2U QTrack<sup>™</sup> Antenna Controller enclosure fits in a standard 19" rack, occupying just 2U of rack space. Mechanical layouts are provided in Figure 3, Figure 4, and Figure 5.



Figure 3: Mechanical Drawing – 2U Front View



Figure 4: Mechanical Drawing – 2U Back View





### 3.2 Environmental

The storage temperature of the QTrack<sup>TM</sup> Antenna System is rated for  $-40^{\circ}$ C to  $+71^{\circ}$ C, while the operating temperature is rated for  $-30^{\circ}$ C to  $+55^{\circ}$ C. It is recommended that the unit be kept in a temperature controlled environment to minimize the risk of operating (or storing) outside the ranges specified.

The 2U Controller features cooling vents on the back of its aluminum chassis. These vents must be kept entirely unobstructed in order to allow for maximum airflow through the system. Whenever feasible, it is helpful to leave an open rack space above and below the 2U Controller for additional heat dissipation.

The QTrack<sup>™</sup> supports an airline fitting for a supply of dehydrated air, and Quasonix recommends that this connection be used whenever the system is deployed outdoors for an extended period. Quasonix offers a dehydrator as an accessory for customers who do not have their own supply of dehydrated air. Contact sales@quasonix.com for details.

### 3.3 Electrical

Two USB ports are located on the front panel along with the power switch and a power indicator, as shown in Figure 6. All 2U Controller electrical connections are located on the rear panel, as shown in Figure 7.



Figure 6: 2U Front Panel

#### 3.3.1 2U Controller Rear Panel Connections

Rear panel connectors are the same for all 2U Controllers. Connectors are present whether the feature is ordered or not. The electrical interface connectors are shown in Figure 7.

### QTrack<sup>™</sup> Antenna System



Figure 7: 2U Rear Panel

Functional descriptions and electrical characteristics for each connector located on the rear panel are described in Table 2.

Name	Description
USB	USB-A 3.0 (blue connector) for local mouse and keyboard
PC HDMI	Local connection to monitor for GUI
Positioner	D38999/20WJ43SN multi-pin connector for control umbilical
USB	USB-A 2.0 (white connector) for local mouse and keyboard
Camera HDMI	Video connection for integrated camera (CA option)
VGA	Female HD-15, Standard VGA video
Ethernet	RJ-45, Enables network access
AGC In	50 Ohm BNC, 1 kOhm, AGC feedback from receiver
AM In	50 Ohm BNC, AM feedback from receiver
TX Clock In	BNC, 75 Ohm TTL, Clock input for optional integrated uplink transmitter
TX Data In	BNC, 75 Ohm TTL, Data input for optional integrated uplink transmitter
Power (far right side)	IEC-320-C14, Supplies AC power to the unit, 110 to 240 VAC, 50/60 Hz

#### Table 2: 2U Rear Panel Connectors

### 4 Operating Instructions

### 4.1 Local Antenna Control Unit (ACU) Operation

The QTrack<sup>™</sup> Antenna System is operated via the PC Interface. With a keyboard, monitor, and mouse, users may connect to the ACU and run the QTrack<sup>™</sup> client software which is located on the desktop.

#### 4.1.1 Remote ACU Operation

The Local ACU and connected QTrack<sup>™</sup> System can be controlled remotely by installing the client software on the remoted device and connecting to the ACU through an Ethernet connection. Figure 8 shows the connections necessary for remote access.

#### IP structure

- Internal
  - 10.1.1.10: QTrack controller
  - 10.1.1.20: Positioner
  - 10.1.1.30: (optional) RS232 serial comms for transmitter control
  - 10.1.1.40: Camera
  - 10.1.1.50: Decoder
- External
  - 172.16.0.10: QTrack controller
  - 172.16.0.40: Camera
  - 172.16.0.50: Decoder

#### 4.1.1.1 Remote Access Set Up, LAN

- 1. Set remote PC IP address to 172.16.0.11/24.
- 2. Install client software on a remote PC.
- 3. Open QTrack ACU desktop icon on remote PC.

A small window displays while attempting to connect. If connection never occurs, click on the ACU Settings button, and ensure QTrack server IP is set to 172.16.0.10.

When connected, full access to ACU functionality should be available from the remote PC.

### QTrack<sup>™</sup> Antenna System



Figure 8: Typical System Configuration, Remote Operation—LAN Access

### 4.2 ACU Main Operations Indicators and Manual Control

This section covers the simple main system operations that are available from the front panel of the ACU Graphical User Interface (GUI). The front panel contains the operational selection buttons, as well as the display feedback readouts and indicators. The System Operation buttons are described in the next section.

Note: Be sure the receiver AM Bandwidth is set to 15,000, and the receiver AGC Scale (dB/V) is set to 20. Connect the Receiver combiner AGC and AM outputs to the respective ACU inputs.

- 1. Connect the ACU to the antenna pedestal, then turn the system on.
- 2. Click on the QTrack ACU desktop icon, as shown in Figure 9.



quasonix-qtrack-client.exe Quasonix, Inc. QTrack Client Quasonix, Inc

Figure 9: QTrack ACU Desktop Icon

The QTrack ACU Graphical User Interface (GUI) displays, as shown in Figure 10.

Note: This display is for a QTrack with the TX option.



Figure 10: QTrack ACU Graphical User Interface

#### 4.2.1 ACU Menu Bar

The ACU Menu Bar consists of icons which provide access to functionality including Logging, Status, Settings, Tools, and Help.

#### 4.2.1.1 Logging

The ACU is equipped with a logging feature which allows tracking status information such as AZ/EL position, tracking error, RSSI, and much more to be logged and saved to a local .txt file.

The Logging icon, shown in Figure 11, enables and disables the logging function. The icon illuminates green when logging is enabled, as shown in Figure 12.

Refer to section 4.5.1 for more detailed information about logging.



Figure 11: Menu Bar, Logging Icon



Figure 12: Menu Bar, Logging Enabled

#### 4.2.1.2 Status

The Status icon, shown in Figure 13, opens a live status reporting window for the motion controller and user inputs, shown in Figure 14.



Figure 13: Menu Bar, Status Icon



Figure 14: Status Window

#### 4.2.1.3 Settings

The Settings icon, shown in Figure 15, opens the Settings window, shown in Figure 16. It is used to set or view parameters within the ACU.



Figure 15: Menu Bar, Settings Icon

👷 Settings				? ×
		- This Computer		
ACU	Hand Wheels	Joystick	Preferences	Network Info
		ACU		
Motion Controller	System Location	Stow	Elevation	
Status Protocol	Designates	Slave Sources	Camera	Advanced
Transmitter				
		— Calibration –		
True North	Tracking			
		Close		

Figure 16: Settings Window

There are three main sections in the Settings window: This Computer, ACU, and Calibration.

#### 4.2.1.3.1 This Computer

This Computer settings let the user Enable, Disable, and Modify user input controls such as hand wheels, joystick, and keyboard. The ACU selection shows the server IP address at 127.0.0.1. **Do not modify this address as it is critical for operation**.

#### 4.2.1.3.2 ACU

The ACU section is used to set system location coordinates and user defined position designates. Refer to section 8 (Appendix A) for transmitter control information. Most other settings in this section should not be modified without Quasonix approval.

#### 4.2.1.3.3 Calibration

Calibration is for True North Settings only. Refer to section 4.3.7 for True North Settings information. Do not modify Tracking settings as these are critical for operation. The QTrack<sup>™</sup> system does not require a periodic calibration.

#### 4.2.1.4 Tools

The Tools icon, shown in Figure 17, opens the Tools window, shown in Figure 18. It is used to set logging parameters, restart and shut down the server, and test joystick and hand wheel inputs. Refer to section 4.5 for more information about the Tools window.



Figure 17: Menu Bar, Tools Icon



Figure 18: Tools Window

#### 4.2.1.5 Help

The Help icon, shown in Figure 19, opens the Help window. The Help window contains contact information, client version, and server version for the unit.



Figure 19: Menu Bar, Help Icon

#### 4.2.2 Axis Control

The Axis Control section, shown in Figure 20, shows the available independent axis control modes, the servo On-Off button, and the (right hand side) Gear Icon (hot buttons) used for immediate display of the linked control and parameter input windows. When activated, those windows display directly to the right of Axis Control.

1. In the Axis Control window, select the red Servo power button, as shown in Figure 20.



Figure 20: Axis Control Window, Red Servo Button

The ACU Servo power button illuminates green, as shown in Figure 21.



Figure 21: Axis Control Window, Servo Button Changed to Green

Note the Azimuth and Elevation indicators with resolution of  $0.01^{\circ}$ , indicating the pedestal pointing in El and AZ frame of reference.



Figure 22: Elevation, Tracking Error, Azimuth Windows

2. On the Axis Control window, select Manual Mode, as shown in Figure 23, and verify that the Hand Wheel Position illuminates green for both Elevation and Azimuth Input Controls.



Figure 23: Axis Control Window, Manual Mode Buttons

 Operate the ACU hand wheels, and verify the pedestal responds both Elevation and Azimuth commands. Alternatively, control the Elevation and Azimuth with the up/down and left/right arrows on the attached keyboard.

#### 4.2.3 Camera Control

1. Click on the Camera button in the top right of the Axis Control pane. The camera control panel displays, as shown in Figure 24.



Figure 24: Camera Control Window

- 2. Select live video to view live video feed.
- 3. Control the camera's Zooming, Focus, and Exposer through this window.

### 4.3 System Tracking

This section describes the basic Azimuth and Elevation searching and tracking functions of the ACU and the attached QTrack System. Azimuth and elevation tracking cannot be independently enabled; only the "both" button is active.

**Note:** During these tests, the receiver and boresight transmitter are tuned for SOQPSK at 1 Mb/s, 2201 MHz (S band). Prior to performing any of the following tracking tests, turn off the boresight power, and zero the receiver AGC. Ensure that the ACU has the appropriate band (L, S, or C) selected for the frequency used. Select the band by clicking on the RX Band button until S band is selected.

#### 4.3.1 Basic Tracking

Basic tracking operation uses the following steps.

- 1. From the ACU, slew the antenna to the boresight.
- 2. Turn on the Boresight RF.
- 3. Select Track. The antenna will slew to the tracking position.
- 4. Select Manual. Change the Azimuth and/or the Elevation by about 10°. Note that when track is engaged, the antenna will reacquire the boresight.

#### 4.3.2 Target Dynamics

Target Dynamics controls the tracking speed of the antenna. It may be desirable to slow the tracking when noise or interference becomes evident.

1. On the Axis Control window, click on the gear button located to the right of the track button, and open the Track Settings window, as shown in Figure 25.



Figure 25: Track Settings Window

- 2. Move the antenna off by about  $10^{\circ}$ . Note the speed in which it tracks.
- 3. In the Track Setting window, set the Target Dynamics slider to about mid-scale. Note the slower tracking speed.
- 4. Set the Target Dynamics slider to about 1/10th scale. Note the slow tracking speed.
- 5. Place the slider back to 100%.

Quasonix recommends that the Target Dynamics slider be set high enough to the follow the target, but no higher. Excessively fast tracking does not improve tracking and may degrade overall system performance.

#### 4.3.3 Multipath Clipping Angle (MPC)

The Multipath Clipping Angle sets the minimum angle that the antenna can point downwards. When a larger signal is observed from a multipath reflection (primarily from the ground), this setting restricts the antenna's lower positioning.

- 1. Track to the center. Select the gear next to the Track button.
- 2. In Track settings, set the MPC Angle [degrees] to about 2 degrees larger than the Elevation tracking angle.
- 3. From the AGC window, select the MPC button. It will turn yellow, as shown in Figure 26, and the minimum elevation will be limited at the MPC Angle.



Figure 26: AGC Window

4. De-select MPC by clicking on the MPC button again. Note that the Elevation angle returns to the original position.

#### 4.3.4 Acquire

Acquire allows the ACU to stop tracking when the received level gets below the Threshold minus the Hysteresis and to re-acquire when the signal level rises above the Threshold.

1. Click on the gear next to the Acquire button to display the Acquire Settings window.



Figure 27: Acquire Settings Window

- 2. Note that the Saturation [dB] and Auto Receiver Threshold [dB] setting do nothing for the QTrack system. They should be set to 99 so they do not activate.
- 3. Set the Threshold to 10 dB and the Hysteresis to 3 dB. These will allow the tracking to continue until the received level reaches 10-3 or 7 dB above the RF Zeroed level.

### QTrack<sup>™</sup> Antenna System

- 4. Adjust the boresight transmitter power level for a received level of approximately 15 dB above AGC Zero. Select Acquire. Verify that the signal is tracking, the Acquire button is yellow, and the Track button is green.
- 5. Decrease the boresights power in 1 dB steps, and verify the Tracking continues until a receive level of less than 7 dB above zero is reached. The Track button turns grey and the position freezes at the last position.
- 6. Increase the signal level until the Track illuminates green indicating it is again tracking. Note that the receive level is greater than 10 dB above Zero.
- 7. De-select Acquire, and return to Manual.

#### 4.3.5 Search

Search allows the ACU to go into search mode when the signal is lost. It uses the threshold and hysteresis values set in the Acquire Settings to activate/deactivate the search pattern.

1. Select the gear next to the Search button to display the Search Settings window.



Figure 28: Search Settings Window

- 2. From the drop down menu, either Box Spiral or Raster search can be selected. Select Box Spiral Search.
- 3. Enter a  $10^{\circ}$  range for both Elevation and Azimuth and a  $5^{\circ}$ /sec Rate for each.
- 4. Set the boresight power for about 40 dB above AGC Zero level.
- 5. On the ACU, select Acquire, then search. Note the system is tracking.
- 6. Remove the boresight power, and the system will enter the defined search pattern.
- 7. Turn the boresight power on, and the QTrack will lock on.
- 8. De-select Acquire, and return to Manual.

#### 4.3.6 Designate Mode

While in manual mode, the user can select the DESIGNATE button (at the top of the Axis Control window, as shown in Figure 29) to enter an Azimuth or Elevation axis commanded angle by clicking on or touching the

### QTrack<sup>™</sup> Antenna System

Up/Down arrows, located just above the program designates list, as shown in Figure 30. The software keypad displays enabling the operator to enter the desired angle, which displays in the Elevation or Azimuth entry field. Selecting the GO button sends the axis to the desired (entered) position. There are two modes: Immediate Designate mode and Program Designate mode, as described in the next sections.



Figure 29: Axis Control Window, Designate Button



Figure 30: Axis Control Window

#### 4.3.6.1 Immediate Designate Mode

- 1. Select Manual mode.
- 2. Select the Designate button in the manual mode area to reveal the Designates Selections.
- 3. In the AZ and EL command angle spin boxes, enter a legitimate coordinate set using the keypad in the dialog box.
- 4. Click on the GO button, and verify that the antenna slews to the designated position  $(+/-0.2^{\circ})$ .
- 5. Select the CLOSE button.
- 6. Verify that the ACU reverts to the manual mode of operation upon completion of the antenna travel, and the Manual mode buttons are returned.

#### 4.3.6.2 Program Designate Mode

- 1. Select Manual.
- 2. Select the Designate Button to reveal the Designates Selections.
- 3. Select a pre-Programmed coordinate set.
- 4. Click on the GO button.
- 5. Verify that the antenna slews to the selected position  $(+/-0.2^{\circ})$ .
- 6. Select the CLOSE button.

7. Verify that the ACU reverts to the Manual mode of operation upon completion of the antenna travel.

#### 4.3.7 True North Calibration

Verify that a True North Calibration capability is available to the operator.

Note: Prior to Setting the North Pointing Position, the Antenna's Earth Location, correct time, and altitude should be entered into the System Location area of the ACU.

1. Select the Settings – Calibration - True North button, as shown in Figure 31, to display the True North window, shown in Figure 32.

👷 Settings				?	×
		- This Computer			
ACU	Hand Wheels	Joystick	Preferences	Network Info	
		ACU			
Motion Controller	System Location	Stow	Elevation		
Status Protocol	Designates	Slave Sources	Camera	Advanced	đ
Transmitter					
		— Calibration —			
True North	Tracking				
		Close			

Figure 31: Settings Window



Figure 32: True North Window

- 2. Verify that values can be manually programmed for the Azimuth angle parameter for the operational modes present (manual and sun).
- 3. Verify that a Clear All Offsets button is present, and that when selected, all True North calibration data is discarded.
- 4. Aim the antenna at the sun.
- 5. Select Use Current Pedestal Position as True North in the north drop down menu.
- 6. Select Apply Offset. Ensure the new Azimuth North pointing angle is present.
- 7. Slew the antenna away from the sun, then select the Designate button in the Manual mode area.
- 8. Choose Sun from the menu, select the GO button, and the antenna should slew back to the sun position.

### 4.4 Slaving and Burn File Operation

The Customer provides pointing data via Ethernet. The ICD can be supplied, if required.

### 4.5 Basic GUI Tool Set Functions

The following Basic GUI (Tool) functions are described in this section. Select the Tools icon from the Tool bar, as shown in Figure 33. Three tool functions can be accessed here: Logging, Hand Wheel Test, and Joystick Test.



Figure 33: Tools Window

### 4.5.1 Logging

1. Select the Logging button to access the Logging window. The Options tab is shown in Figure 34.





- 2. Turn on all available logging parameters for recording.
- 3. Close the Logging Window and the Settings Menu.
- 4. Select the Logger Icon from the Tool bar. It should turn green when selected (the Logger function is recording).
- 5. Turn the logging off by reselecting the Logger icon in the lower tool bar.
- 6. Return to the Logging window, Log Files tab, to ensure a log file has been created.
- 7. Click Download to save the file to desired location.

#### 4.5.2 Hand Wheel Test (Optional)

1. Enable optional hand wheels by selecting the Settings button from the Tool bar.



Figure 35: Elevation and Azimuth Input Control Windows

- 2. Select the Hand Wheels button, then check the enable hand wheels box.
- 3. Click on Save and close the Settings window.
- 4. Select the Tools Icon from the Tool bar.
- 5. Select the Hand Wheel Test.



Figure 36: Hand Wheel Test Window

6. Rotate the Azimuth hand wheel. Ensure the Azimuth on-screen pointer rotates with the ACU hand wheel input.

7. Rotate the Elevation hand wheel. Ensure the on-screen Elevation pointer rotates with the EL hand wheel input.

#### 4.5.3 Joystick Test (Optional)

- 1. Enable the optional Joystick by selecting the Settings button from the tool bar.
- 2. Select the Joystick button and check the Enable box.
- 3. Select desired joystick from drop down menu.
- 4. Click on Save and close the Settings window.
- 5. Select the Tools icon from the tool bar.
- 6. Select the Joystick button to launch the Joystick test window.



Figure 37: Joystick Test Window

- 7. Move the attached joystick in the Azimuth direction (side to side) and be sure the Joystick test follows the motion on the window.
- 8. Move the joystick in the Elevation direction (up and down), and ensure the test follows on the window.

### 5 Maintenance Instructions

The QTrack<sup>™</sup> Antenna System requires no regular maintenance, but the battery in the 2U Rack Mount Controller may need to be replaced every 2-3 years.

### 5.1 Replace the Battery

- 1. Remove the top cover by unscrewing the eight (8) Philips head screws.
- 2. Locate the motherboard in the front right of the unit.
- 3. Replace the 2032 coin cell battery located next to the RAM, as shown in Figure 38.



Figure 38: Location of Battery on Motherboard of Older Units

In newer units, the battery may be located in a slightly different location on the board, as shown in Figure 39. Newer units require a 2032 coin cell battery with a Molex connector.



Figure 39: Location of Battery on Newer Units

- 4. After installing the new battery, replace the cover and all eight Philips head screws.
- 5. Apply power to the 2U controller.
- 6. Ensure the computer system clock is accurate.



# 6 Product Warranty

The QTrack<sup>™</sup> Antenna System carries a standard parts and labor warranty of one (1) year from the date of delivery.

# 7 Technical Support and RMA Requests

In the event of a product issue, customers should contact Quasonix via phone (1-513-942-1287) or e-mail (support@quasonix.com) to seek technical support. If the Quasonix representative determines that the product issue must be addressed at Quasonix, a returned materials authorization (RMA) number will be provided for return shipment.

Authorized return shipments must be addressed in the following manner:

#### Quasonix, Inc. ATTN: Repair, RMA # 6025 Schumacher Park Drive West Chester, OH 45069

To ensure that your shipment is processed most efficiently, please include the following information with your product return:

- Ship To Company name, address, zip code, and internal mail-drop, if applicable
- Attention/Contact person Name, Title, Department, Phone number, email address
- Purchase Order Number If applicable
- RMA Number provided by the Quasonix representative

Please note that Quasonix reserves the right to refuse shipments that arrive without RMA numbers.

### 8 Appendix A – Transmitter Control

A QTrack<sup>TM</sup> system with the TX(xx) option has an embedded uplink transmitter. These systems operate in both L and S bands, and must transmit and receive in separate bands.

The QTrack<sup>™</sup> ACU GUI contains a Tx Control window, as shown in Figure 40, to facilitate transmitter operation.



Figure 40: QTrack ACU Graphical User Interface

The Tx Control window displays frequency and modulation (band) settings. Two LED indicators provide connectivity and RF status. The two buttons enable/disable transmitter and RF Output.

Tx Control –	
Frequency [MHz]:,	Connected
Modulation:	🛑 RF Output
Tx S-Band RF Output: OFF	

Figure 41: Tx Control Window

### QTrack<sup>™</sup> Antenna System

To set the transmit frequency and other parameters, select the settings (gear) button in the lower right corner for the Tx Control window. The Transmitter window, Tx Settings tab is shown in Figure 42.



Figure 42: Transmitter Window, Tx Settings Tab

There are three tabs available on the Transmitter window: Tx Settings, Console, and Comm. Config.

- TX Settings Contains typical transmitters settings for Frequency, Modulation, and Variable Power. Ensure the selected transmit frequency is in a different band than the desired receive band. The ACU will not enable RF if this set the same as the receive band.
- Console tab Provides the serial interface to the transmitter
- Comm. Config Contains IP address information for the transmitter serial interface. **Do not modify these parameters as they are critical for system operation**.

9	Appendix	В –	Acronym	List
---	----------	-----	---------	------

Acronym	Description
ACU	Antenna Control Unit
AGC	Automatic Gain Control
AM	Amplitude Modulation
AQPSK	Variant of Quadrature Phase Shift Keying
ARTM	Advanced Range Telemetry
AUQPSK	Variant of Quadrature Phase Shift Keying
AZ	Azimuth
BEP	Bit Error Probability
BER	Bit Error Rate
BNC	Bayonet Neill-Concelman Connector (RF Connector)
BPSK	Binary Phase Shift Keying
CCW	Counterclockwise
CD	Compact Disk
СРМ	Continuous Phase Modulation
CW	Clockwise
CWM	Cable Wrap Meter
DACU	Digital Antenna Control Unit
DB-9	D-subminiature 9 pin Serial Connector
DC	Diversity Combiner
DHCP	Dynamic Host Configuration Protocol
DPM	Digital Phase Modulation
DQE	Data Quality Encapsulation
DQM	Data Quality Metric
EL	Elevation
FPGA	Field Programmable Gate Array
G/T	Gain per Temperature
GPS	Global Positioning System
GUI	Graphical User Interface

Acronym	Description
IF	Intermediate Frequency
IP	Internet Protocol
kbps	Kilobits per second
KHz	Kilohertz
LCD	Liquid Crystal Display
LDPC	Low Density Parity Check
LED	Light-emitting Diode
LHCP	Left Hand Circularly Polarized
LNA	Low Noise Amplifier
mbps	Megabits per second
MCX	Snap on subminiature connector
МНСРМ	multi-h Continuous Phase Modulation
MHz	Megahertz
MPC	Multipath Clipping Control
Ν	(connector type) Threaded RF connector
OQPSK	Offset Quadrature Phase Shift Keying
РСВ	Printed Circuit Board
PCMFM	Pulse Code Modulation/Frequency Modulation
PM	Phase Modulation
PSK	Phase Shift Keying
QPSK	Offset Quadrature Phase Shift Keying
RDMS	Receiver DeModulator Synchronizer
RF	Radio Frequency
RHCP	Right Hand Circularly Polarized
RJ-45	Ethernet Connection Jack
RM	Rack-Mount
RS-232	Recommended Standard 232 (Serial Communications)
SAW	Sawtooth Wave
SDI	System Degradation Indication
SNR	Signal to Noise Ratio

Acronym	Description
SOQPSK	Shaped Offset Quadrature Phase Shift Keying
SOQPSK-TG	Shaped Offset Quadrature Phase Shift Keying – Telemetry Group
STC	Space-Time Coding
TDC	Top Dead Center
TRL	Tracking Loop
TTL	Transistor Logic
UDP	User Datagram Protocol
UQPSK	Unbalanced Quadrature Phase Shift Keying
USB	Universal Serial Bus
VAC	Voltage Alternating Current
WAN	Wide Area Network