

TRANSMITTER PINOUT CODE N4

Connector: SAMTEC FTSH-108-04-F-D (TOP)



Pin	Function		
1	LVTTL Serial Control Input to Transmitter		
2	LVTTL Serial Control Reply from Transmitter		
3	N/C		
4	N/C		
5	TTL Clock		
6	TTL Data		
7	TTL Clock and Data Ground		
8	RF On/Off		
9	N/C		
10	N/C		
11	N/C		
12	N/C		
13	N/C		
14	N/C		
15	DC Power Return		
16	DC Power In		



DRAWING	qsx_pcn4.docx		
REVISION	В		
DRAWN	MRE	DATE	08-16-2018
VERIFIED	NFE	DATE	08-16-2018
APPROVED	DEF	DATE	08-16-2018