

## Technical Guide

# Field Replacement of Transmitter SMA

Quasonix, Inc.  
6025 Schumacher Park Dr.  
West Chester, OH 45069  
01 February 2022

**\*\*\* Revision 1.0 \*\*\***

Specifications subject to change without notice.

All Quasonix products are under U.S. Department of Commerce jurisdiction; not covered by ITAR

Quasonix transmitter SMA connectors may be replaced in the field, after acquiring the SMA replacement kit from the factory.

1. Remove the damaged SMA connector using a #1 Phillips screwdriver.
2. Replace the damaged parts with the correct parts obtained from Quasonix.
3. Apply Loctite 242 to the threads on #2-56 x 3/16 pan head screws.
4. Reassemble the connector in the order shown.

